

# Contents

I

## Challenges of a Precision Engineer

<b>1</b>	<b>Speak the right language</b>	<b>3</b>
1.1	Translate requirements to specifications	3
1.2	Definitions	4
1.2.1	Degrees of freedom	4
1.2.2	Target, true and observed value	5
1.2.3	Resolution	6
1.2.4	Tolerance and allowance	6
1.2.5	Precision, repeatability, reproducibility, trueness and accuracy	7
<b>1.3</b>	<b>Schematic representation</b>	<b>8</b>
1.3.1	Schematic representation of basic elements	8
<b>2</b>	<b>Comprehend physical effects</b>	<b>11</b>
2.1	Compliance or lack of stiffness	11
2.2	Inertia	12
2.3	Thermal effect	13
2.4	Shortening effect	14
2.5	Play	15
2.6	Friction, stick, spin, slip and sliding	16
2.7	Vibrations	20

<b>2.8</b>	<b>Hysteresis, virtual play and micro-slip</b>	<b>23</b>
2.8.1	Hysteresis . . . . .	23
2.8.2	Virtual play . . . . .	25
2.8.3	Micro-slip . . . . .	26
<b>2.9</b>	<b>Other physical effects</b>	<b>28</b>
<b>3</b>	<b>Select optimal strategies</b>	<b>29</b>
<b>4</b>	<b>Predict system behaviour</b>	<b>35</b>

## II

## Toolbox of a Mechanical Engineer

<b>5</b>	<b>System stiffness</b>	<b>39</b>
<b>5.1</b>	<b>Parallel and series</b>	<b>39</b>
<b>5.2</b>	<b>Effect of a spring at another location</b>	<b>41</b>
5.2.1	Effect of a translational spring at the point of interest . . . . .	41
5.2.2	Effect of a rotational spring at the axis of interest . . . . .	42
5.2.3	Effect of a translational spring at the axis of interest . . . . .	44
5.2.4	Effect of a rotational spring at the point of interest . . . . .	45
<b>5.3</b>	<b>Energy method</b>	<b>45</b>
5.3.1	Example: stiffness of a truss . . . . .	46
5.3.2	Example: stiffness of a shaft . . . . .	47
5.3.3	Example: stiffness of multiple springs in a circular lay-out . . . . .	49
<b>5.4</b>	<b>Systems with a preload</b>	<b>50</b>
<b>5.5</b>	<b>Centre of stiffness</b>	<b>51</b>
<b>6</b>	<b>Element stiffness and loadability</b>	<b>53</b>
<b>6.1</b>	<b>Rotational stiffness for torsion</b>	<b>54</b>
6.1.1	Twisting, warping and stiffening effect . . . . .	54
6.1.2	Torsional and warping stiffness . . . . .	56
<b>6.2</b>	<b>Rotational stiffness for bending</b>	<b>61</b>
6.2.1	Cantilever beam subjected to a bending moment . . . . .	61
6.2.2	Simply supported beam subjected to a moment . . . . .	62
6.2.3	Composed beam subjected to a moment . . . . .	62
<b>6.3</b>	<b>Translational stiffness for lateral deformation</b>	<b>66</b>
6.3.1	Cantilever beam subjected to a transverse force . . . . .	66
6.3.2	Simply supported beam subjected to a transverse force . . . . .	68
6.3.3	Cantilever beam forced into a straight lateral displacement . . . . .	69

<b>6.4</b>	<b>Translational stiffness for longitudinal deformation</b>	<b>71</b>
6.4.1	Beam subjected to a longitudinal force . . . . .	71
6.4.2	Composed beam subjected to a longitudinal force . . . . .	72
6.4.3	Cantilever beam subjected to eccentric longitudinal force . . . . .	72
6.4.4	Deformed composed beam subjected to longitudinal force . . . . .	74
6.4.5	Loadability for compression . . . . .	76
<b>7</b>	<b>Contact stiffness and loadability</b> . . . . .	<b>81</b>
<b>7.1</b>	<b>Approximating stiffness and loadability</b>	<b>83</b>
7.1.1	Transferring variables to a set of parameters . . . . .	83
7.1.2	Stresses, deformation and stiffness for elliptical contact areas . . . . .	85
7.1.3	Stresses, deformation and stiffness for rectangular contact areas . . . . .	87
<b>8</b>	<b>Parasitic displacement</b> . . . . .	<b>89</b>
<b>8.1</b>	<b>Parasitic displacement due to shortening</b>	<b>89</b>
<b>9</b>	<b>Static behaviour</b> . . . . .	<b>91</b>
<b>9.1</b>	<b>Static characteristics</b>	<b>91</b>
9.1.1	Static characteristics of basic elements . . . . .	91
9.1.2	Static characteristics of some basic systems . . . . .	92
9.1.3	Total play in systems with multiple springs . . . . .	100
9.1.4	Example of static characteristic . . . . .	101
<b>9.2</b>	<b>Systems with micro-slip</b>	<b>105</b>
9.2.1	Micro-slip in a clamp . . . . .	105
9.2.2	Micro-slip in a bolted joint . . . . .	109
9.2.3	Micro-slip in a belt drive . . . . .	109
<b>10</b>	<b>Dynamic behaviour</b> . . . . .	<b>113</b>
<b>10.1</b>	<b>Free vibration in the time domain</b>	<b>113</b>
10.1.1	Free vibration without damping . . . . .	113
10.1.2	Free vibration with viscous damping . . . . .	114
<b>10.2</b>	<b>Forced vibration in the time domain</b>	<b>117</b>
10.2.1	Forced vibration without damping . . . . .	117
10.2.2	Forced vibration with viscous damping . . . . .	119
<b>10.3</b>	<b>Force vibration in the frequency domain</b>	<b>121</b>
<b>10.4</b>	<b>Analysis of damping</b>	<b>123</b>
10.4.1	Relation between damping ratio and specific damping capacity .	123
10.4.2	Relation between damping ratio and decrement for free vibration	124
10.4.3	Relation between damping ratio and 3dB-bandwidth . . . . .	125

10.4.4	Graphical representation of $\zeta$ in a root locus plot . . . . .	125
--------	--------------------------------------------------------------------	-----

## **11 Thermal behaviour . . . . .** 127

<b>11.1</b>	<b>Temperature change</b> . . . . .	<b>127</b>
11.1.1	Effect of change in temperature on homogeneous object . . . . .	127
11.1.2	Effect of change in temperature on bimaterial object . . . . .	129
11.1.3	Effect of change in energy on temperature . . . . .	130
<b>11.2</b>	<b>Energy transfer by heat</b> . . . . .	<b>131</b>
11.2.1	Thermal radiation . . . . .	131
11.2.2	Conduction . . . . .	131
11.2.3	Radiation versus conduction . . . . .	132

## **III Design strategies for precision engineering**

### **12 Low stress relationships . . . . .** 135

<b>12.1</b>	<b>Introduction to degrees of freedom</b> . . . . .	<b>135</b>
<b>12.2</b>	<b>Design exact-constraint</b> . . . . .	<b>139</b>
12.2.1	Why design exact-constraint . . . . .	139
12.2.2	Basic elements for constraining . . . . .	142
12.2.3	Elements in parallel . . . . .	145
12.2.4	Elements in series . . . . .	147
12.2.5	Analysing degrees of freedom . . . . .	149
12.2.6	Designing degrees of freedom . . . . .	150
12.2.7	Degrees of freedom exercises . . . . .	151
12.2.8	Adding redundant constraints . . . . .	151
12.2.9	Methods for analysing degrees of freedom . . . . .	153
<b>12.3</b>	<b>Use elastic averaging</b> . . . . .	<b>153</b>
<b>12.4</b>	<b>Avoid a step in the stiffness</b> . . . . .	<b>154</b>

### **13 Minimise deviation . . . . .** 157

<b>13.1</b>	<b>Minimise load on the system</b> . . . . .	<b>157</b>
13.1.1	Use a force-frame . . . . .	158
13.1.2	Strive for a constant temperature . . . . .	158
13.1.3	Neutralise acceleration forces . . . . .	159
13.1.4	Reduce impact forces . . . . .	160
13.1.5	Isolate vibrations . . . . .	160

<b>13.2 Strive for a high stiffness</b>	<b>161</b>
13.2.1 Aim for a favourable transmission ratio . . . . .	161
13.2.2 Design in parallel . . . . .	161
13.2.3 Optimise stiffnesses of compliant elements in series . . . . .	163
13.2.4 Choose a short force path . . . . .	163
13.2.5 Apply loads in stiff directions . . . . .	164
13.2.6 Strive for a high element stiffness . . . . .	167
13.2.7 Strive for a high contact stiffness . . . . .	167
<b>13.3 Strive for a low mass</b>	<b>170</b>
13.3.1 Aim for lightweight and stiff . . . . .	171
13.3.2 Use two-stage systems . . . . .	179
<b>13.4 Strive for a high damping</b>	<b>180</b>
13.4.1 Viscous damping . . . . .	182
13.4.2 Coulomb damping . . . . .	183
13.4.3 Hysteretic damping . . . . .	183
13.4.4 Eddy current damping . . . . .	186
13.4.5 Tuned mass damping . . . . .	186
<b>13.5 Strive for thermal stability</b>	<b>190</b>
13.5.1 Aim for zero or equal deformation . . . . .	190
13.5.2 Choose the optimal location for the centre of thermal expansion .	191
<b>13.6 Eliminate or minimise position errors</b>	<b>192</b>
13.6.1 Prevent warping . . . . .	193
13.6.2 Use symmetric designs . . . . .	193
13.6.3 Average errors . . . . .	194
13.6.4 Compensate for undesirable displacement . . . . .	196
<b>13.7 Optimise measurement and control</b>	<b>197</b>
13.7.1 Use a metro-frame . . . . .	197
13.7.2 Aim for an optimal measurement . . . . .	197
13.7.3 Choose optimal position for actuator and sensor . . . . .	198
13.7.4 Correct the control value . . . . .	200
<b>14 Prevent relative movement</b>	<b>201</b>
<b>14.1 Avoid (micro-)slip</b>	<b>201</b>
14.1.1 Design monolithic systems . . . . .	201
14.1.2 Use screwing . . . . .	202
14.1.3 Use adhesives or welding . . . . .	202
14.1.4 Avoid difference in strain . . . . .	203
<b>14.2 Minimise difference in strain</b>	<b>204</b>
14.2.1 Align neutral lines for bending . . . . .	204
14.2.2 Optimise clamping . . . . .	204

<b>14.3</b>	<b>Add preload</b>	<b>206</b>
14.3.1	Avoid play . . . . .	206
14.3.2	Provide preload force . . . . .	207
<b>14.4</b>	<b>Prevent movement in one direction</b>	<b>208</b>
<b>15</b>	<b>Facilitate relative movement . . . . .</b>	<b>209</b>
<b>15.1</b>	<b>Avoid all mechanical contact</b>	<b>210</b>
15.1.1	Avoid physical contact using ferrofluid bearings . . . . .	210
15.1.2	Avoid physical contact using hydrostatic bearings . . . . .	211
15.1.3	Avoid physical contact using aerostatic bearings . . . . .	211
15.1.4	Avoid physical contact using magnetic bearings . . . . .	212
<b>15.2</b>	<b>Use flexure mechanisms</b>	<b>212</b>
15.2.1	Use sheet flexure as hinge . . . . .	213
15.2.2	Use cross flexures as hinge . . . . .	214
15.2.3	Use parallel flexures as linear guide . . . . .	216
15.2.4	Reinforced flexures with mid-section . . . . .	218
15.2.5	Use notch hinges . . . . .	219
15.2.6	Aim for low or zero stiffness . . . . .	222
<b>15.3</b>	<b>Optimise sliding</b>	<b>223</b>
15.3.1	Minimise friction force . . . . .	224
15.3.2	Minimise the effects of wear . . . . .	225
<b>15.4</b>	<b>Optimise rolling</b>	<b>226</b>
15.4.1	Rolling bearings . . . . .	227
15.4.2	Strive for pure rolling . . . . .	227
15.4.3	Rolling in a hinge . . . . .	228
<b>16</b>	<b>Manage energy . . . . .</b>	<b>231</b>
<b>16.1</b>	<b>Store energy</b>	<b>231</b>
16.1.1	Store kinetic energy by using a balance mass . . . . .	231
16.1.2	Store elastic potential energy by using springs . . . . .	232
16.1.3	Store potential energy by using a mass and a spring . . . . .	233
<b>16.2</b>	<b>Dissipate energy</b>	<b>235</b>
16.2.1	Use friction for braking . . . . .	235
16.2.2	Use eddy current braking . . . . .	235
16.2.3	Use plastic deformation . . . . .	235

**IV****Design concepts for precision designs**

<b>17</b>	<b>Linear guiding .....</b>	<b>239</b>
17.1	Parallel sheet flexures as linear guide	239
17.2	Carriage with V-groove on rail with spindel drive	241
17.3	Carriage with V-groove with magnetic drive, AAE	243
17.4	Slide with ball screw, University of Twente	245
17.5	Conveyor belt for linear motion	246
17.6	Conveyor belt for positioning, Sioux-CCM	249
<b>18</b>	<b>Manipulating and adjusting .....</b>	<b>253</b>
18.1	Manipulators with a high transmission ratio	253
18.2	Mechanisms with notch hinges	254
18.3	Manipulator for six degrees of freedom	255
18.4	Adjustment in two DOF in a printhead, NTS	256
<b>19</b>	<b>High dynamic positioning .....</b>	<b>259</b>
19.1	Positioning of crystals, MI Partners	259
19.2	High dynamic manipulating of optical stage, JPE	264
<b>20</b>	<b>Torque transmission .....</b>	<b>267</b>
20.1	Coupling of suspended shafts with one rod	267
20.2	Coupling of suspended shafts using four flexures	268
20.3	Coupling of suspended shafts with a hollow tie rod	269
20.4	Helical coupling in a printer, Canon	269
20.5	Self centring couplings	270

**V****Appendices**

<b>A</b>	<b>Efficiency of beams .....</b>	<b>275</b>
<b>B</b>	<b>Answers to exercises .....</b>	<b>281</b>
<b>C</b>	<b>Tables .....</b>	<b>283</b>
	<b>Bibliography .....</b>	<b>289</b>

**Index .....** **295**